



Technical Bulletin #1506

Transmission: 6T70

Subject: *Torque Converter Installation/Removal*

Application: *GM*

Issue Date: *January, 2013*

6T70

Torque Converter Installation/Removal

Torque converter lifting handles can be used as an alternative method for supporting the transmission assembly during repairs. Only install these handles until they stop. Do not tighten. Over tightening these handles can cause damage to the torque converter. Failure to raise the torque converter straight up could damage the torque converter clutch lip seal inside the torque converter clutch assembly.

